



PV1 string

PV2 string

PV3 string

Wind turbine

Wind controller

PV1 DC CB

PV2 DC CB

PV3 DC CB

Wind DC CB

DC DIAGRAM

For the most up to date information please visit: www.redx.com.au or scan QR code below:



240V DIAGRAM

For the most up to date information please visit: www.redx.com.au or scan QR code below:



MPPT1 MPPT2 MPPT3 LVBUS_Wind
Redx RX7000HY

RS485 Comms connector

Grid connector

EPS connector

Neutral bar

PE bar

GRID

GRID CT

Main Grid CB

MCB for RX7000 "GRID"

Smart-meter

MCB for RX7000 "EPS"

RCD for EPS Load

EPS LOAD